


6. Automatic descaling program


1. Alarm.

- Red and Blue LED flickers.



2. Preparation.


- Lift the front of the TOP COVER first and open it by lifting it up.



- Turn the Limestone cover to the left to open it.


3. Press the Cleansing + Bidet button for 5 seconds.

- Blue LED displays.
- Blue LED blinks in 5 sec.




4. Blue LED blinks.
 - Insert the descaling liquid.


* Use only the original Hygea - Durgol® descaling liquid provided in the accessory box or purchased from your local distributor.
The use of a descaling liquid different from the original one may cause malfunctions to the product.




5. Press the Bidet button.
 - Purple LED turns on for 10 sec.



6. White LED turns on.
 - Limestone removal and cleansing in progress.
 - Operates for 42 minutes.



7. Purple LED turns on.
 - Additional cleansing proceeded.
 - Operates for 10-11 minutes.



8. Returns to the initial settings.